



Detail #	Name
1	Front jaw (2 req'd)
2	Top plate
3	Bottom plate
4	Front pin
5	Safety button
6	Retaining ring
7	Spring (safety)
8	Link (4 req'd)
9	Short pin
10A	Actuator A (f.o.t.)
10B	Actuator B (s.i.t.) not shown
11	Actuator C
12A	Trigger (folding)
12B	Trigger (screw in) not shown
13	Long pin
14	Spring (main)
15	Spring (detent)
16	Ball (detent)
17	Button housing (safety)
18	Screw (2 req'd)
19	Washer
20A	Bent stud
20B	Ball end screw, not shown
21	Nut
22A	Ball end connector
22B	Clevis, not shown
23	Swing arm (2 req'd) not shown
24	Clevis pin, not shown
25	Retaining ring, not shown
26	Swing arm ring (2 req'd) not shown
27	Leather strap, not shown
28	Sensitivity screw
29	Web strap assy., not shown
30	Owners manual
31	Thumb button, not shown
32	3/32 allen wrench, not shown
33	1/16 allen wrench, not shown

All questions may be answered and replacement parts obtained by calling or writing to Overkill R&D, Inc.